GX4pro



User Manual





CONTENT

Declarations	3
Installation Safety Summary	4
Chapter 1 Your Product	
1.1 In the Box	6
1.2 Product Overview	7
1.2.1 Rear Panel	8
1.2.2 Front Panel	
1.2.3 Dimension	11
Chapter 2 Install Your Product	
2.1 Plug in Signals	12
2.2 Plug in Main Power	12
2.3 Turn on Your Product	
Chapter 3 Use Your Product	
3.1 Use the MENU Button	13
3.2 MENU Structure	
3.3 Use the Menu	
3.3.1 LED Configuration	
3.3.2 Out Bright	
3.3.3 Input	
3.3.4 Output	
3.3.5 Transition	
3.3.6 Audio	23
3.3.7 Split	
3.3.8 System	
3.3.9 Language	
3.3.10 Factory Reset	
3.4 Shortcut Buttons	
3.4.1 【TAKE】 Button	
3.4.2 【PIP】 Button	27
3.4.3 【SCALE】 Button	
3.4.4 【SAVE】Button	
3.4.5 【LOAD】 Button	
Chapter 4 Ordering Codes	
4.1 Product	
4.2 Options	
Chapter 5 Support	
5.1 Contact Us	
Chapter 6 Appendix	
6.1 Specification	
6.2 Load LED Configuration File	34
6.3 Terms & Definitions	41
6.4 Revision History	



Thank you for choosing our product!

This User Manual is designed to show you how to use this video processor quickly and make use of all the features. Please read all directions and instructions carefully before using this product.

Declarations

FCC/Warranty

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause harmful interference, in which case the user will be responsible for correcting any interference.

Guarantee and Compensation

RGBlink provides a guarantee relating to perfect manufacturing as part of the legally stipulated terms of guarantee. On receipt, the purchaser must immediately inspect all delivered goods for damage incurred during transport, as well as for material and manufacturing faults. RGBlink must be informed immediately in writing of any complains.

The period of guarantee begins on the date of transfer of risks, in the case of special systems and software on the date of commissioning, at latest 30 days after the transfer of risks. In the event of justified notice of compliant, RGBlink can repair the fault or provide a replacement at its own discretion within an appropriate period. If this measure proves to be impossible or unsuccessful, the purchaser can demand a reduction in the purchase price or cancellation of the contract. All other claims, in particular those relating to compensation for direct or indirect damage, and also damage attributed to the operation of software as well as to other service provided by RGBlink, being a component of the system or independent service, will be deemed invalid provided the damage is not proven to be attributed to the absence of properties guaranteed in writing or due to the intent or gross negligence or part of RGBlink.

If the purchaser or a third party carries out modifications or repairs on goods delivered by RGBlink, or if the goods are handled incorrectly, in particular if the systems are commissioned operated incorrectly or if, after the transfer of risks, the goods are subject to influences not agreed upon in the contract, all guarantee claims of the purchaser will be rendered invalid. Not included in the guarantee coverage are system failures which are attributed to programs or special electronic circuitry provided by the purchaser, e.g. interfaces. Normal wear as well as normal maintenance are not subject to the guarantee provided by RGBlink either.

The environmental conditions as well as the servicing and maintenance regulations specified in this manual must be complied with by the customer.



Operators Safety Summary

The general safety information in this summary is for operating personnel.

Do Not Remove Covers or Panels

There are no user-serviceable parts within the unit. Removal of the top cover will expose dangerous voltages. To avoid personal injury, do not remove the top cover. Do not operate the unit without the cover installed.

Power Source

This product is intended to operate from a power source that will not apply more than 230 volts rms between the supply conductors or between both supply conductor and ground. A protective ground connection by way of grounding conductor in the power cord is essential for safe operation.

Grounding the Product

This product is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before connecting to the product input or output terminals. A protective-ground connection by way of the grounding conductor in the power cord is essential for safe operation.

Use the Proper Power Cord

Use only the power cord and connector specified for your product. Use only a power cord that is in good condition. Refer cord and connector changes to qualified service personnel.

Use the Proper Fuse

To avoid fire hazard, use only the fuse having identical type, voltage rating, and current rating characteristics. Refer fuse replacement to qualified service personnel.

Do Not Operate in Explosive Atmospheres

To avoid explosion, do not operate this product in an explosive atmosphere.

Installation Safety Summary

Safety Precautions

For all GX4pro processor installation procedures, please observe the following important safety and handling rules to avoid damage to yourself and the equipment.

To protect users from electric shock, ensure that the chassis connects to earth via the ground wire provided in the AC power Cord. The AC Socket-outlet should be installed near the equipment and be easily accessible.



© Xiamen RGBlink Science & Technology Co., Ltd.

Unpacking and Inspection

Before opening GX4pro processor shipping box, inspect it for damage. If you find any damage, notify the shipping carrier immediately for all claims adjustments. As you open the box, compare its contents against the packing slip. If you find any shortages, contact your sales representative.

Once you have removed all the components from their packaging and checked that all the listed components are present, visually inspect the system to ensure there was no damage during shipping. If there is damage, notify the shipping carrier immediately for all claims adjustments.

Site Preparation

The environment in which you install your VENUS X1 should be clean, properly lit, free from static, and have adequate power, ventilation, and space for all components.

Chapter 1 Your Product

1.1 In the Box







Note: AC Power Cable supplied as standard according to destination market.



1.2 Product Overview

GX4pro is an video processor which supports DVI output resolution at 2048x1152@60 and offers multiple test pattern output resolution options. Beside standard with a 1 HDMI (with loop), 1 CVBS, 1 VGA, 1 DVI and 1 pair of Audio analog connectors, it also comes with 1 empty module slots for any single input modules selecting from HDMI,DP,DVI,SDI,VGA,CVBS and USB modules. Capability of support any input makes GX4pro have features of PIP (dual pictures),synchronized video with audio control and seamless switching between different inputs. Moreover Extended Display Identification Data(EDID management) make sure display perfectly spot to spot.

GX4pro can work as LED display controller when universal senders cards is installed. There are 2 empty slots fitting for one 2.6mega pixels sender card or two 1.3mega pixels sender cards. RGBlink dedicated sender card module SubitoNX[™] Quatro is also an an option to control LED display. It provides 2.3 mega pixels display up to horizontal 3840 pixels or vertical 1920 pixels, through 4 RJ45 ports.



GX4pro with SubitoNX Quatro Module

Note:GX4pro is also compatible with sender cards from Novastar,Linsn Technology,Colorlight and Mooncell.But GX4pro only supports power supply to the sender cards from other companies and can not control them.



1.2.1 Rear Panel



INPUT CONNE	CTORS
1	1 specific slot for optional SDI module
2	1 slot for optional module
3	VGA input
4	CVBS Input
5	HDMI In/Loop
6	DVI input
7	Audio input
OUTPUT CONNECTORS	
8	Audio Output
9	DVI Output
10	Slots preserved for sender cards
POWER	
11	Power switch
12	Power IEC-3
CONTROL PORT	
13	USB-A
10	RS232



1.2.2 Front Panel

				NENU PIP SAVE DBK 1 SOALE SPLIT LOAD	HDMI CVBS VGA DVI 2 3 4 5 SDI COULE 4UD10 BLACK	
--	--	--	--	--	---	--

OLED Display

Displays current status of the product, and for feature selections provides interactive
choices in conjunction with buttons on the front panel.

Rotary Knob



This knob used for menu selections and confirmation.

turn to left and right to select menu item and push to confirm selection.

Buttons

MENU	This button used for menu selections Push the button again will return to the last level
	menu or exit the menu.
PIP	PIP/DSK Button
	PIP and DSK function reuse button.
DSK	Push the button to enter to the PIP menu items.
SCALE	This button used for size and position adjusting.
	When input USB signal, it reused the stop and play button, push the button to stop or
	play the USB video file.
SPLIT	Split function button.
	When connect USB signal, it reused the move next button, push the button to play the
	next USB video file.
SAVE	Save all current settings to 1 -16 scene and Number 1.
1	
LOAD 6	Restores/Loads saved setting from 1-16 scene and Number 6.
HDMI	HDMI input source selection and Number 2
2	
CVBS	
3	CVBS input source selection and Number 3
3	
VGA	VGA input source selection and Number 4.
4	

 $\ensuremath{\mathbb{C}}$ Xiamen RGBlink Science & Technology Co., Ltd.

DVI 5	CVBS input source selection and Number 5.
SD I 7	SDI input source selection and Number 7.
MODULE	After optional input module is fitted, this button is to select the optional input source.
8	Number 8.
AUD I 0 9	Short cut button of Audio Menu and Number 9
BLACK 0	Short cut button of Black Out and Number 0.
TAKE	Switch button with transition effect.

1.2.3 Dimension

Following is the dimension of GX4pro for your reference::

Dimension:480mm×303mm×45mm











Chapter 2 Install Your Product

2.1 Plug in Signals

Connect signals to the product (ensure all devices are powered off first). Tighten connector screws/locks where provided.

2.2 Plug in Main Power

Connect IEC cable to device and plug into wall socket. Turn on power at wall socket.

2.3 Turn on Your Product

Turn the power switch on the rear to ON position.

TST screen shows as below, meanwhile the device enter initializing state after that, the device will load the previously saved setting. On delivery, the default input is HDMI.



Chapter 3 Use Your Product

3.1 Use the MENU Button

Push 【MENU】 button to enter main menu.

Turn the knob to select corresponding menu item.

The symbol >indicate that the item is selected.

Push the knob to confirm the operation.

The symbol * means the selected item is under editing state, ready to be set or checked The operation diagram is as follows:



3.2 MENU Structure

The MENU structure is shown in the figure below:

LED CONFIG	INPUT	OUTPUT	TRANSITION	AUDIO
QUICK CONNECT	INPUT INFO	OUTPUT INFO	MODE	MUTE
ADVANCED	SIZING ADJUST	OUTPUT FORMAT	DURATION	VOLUME
CONFIG FILE	USB CONTROL	OUTPUT ADJUST	ALPHA	AUDIO IN
	VGA ADJUST	SCREEN	DEINTERLACE	HDMI
	ADC ADJUST	RATIO	IMAGE ENHANCE	
	SDI ADJUST	PICTURE	TAKE	
	EDID MANAGE	TEXT OVERLAY		
	VGA TYPE	DISPLAY MODE		
	DVI(4 IN 1)	GAMMA		
SPLIT	SYSTEM	LANGUAGE	FACTORY RESET	
SPLIT ON/OFF	SYSTEM INFO	LANGUAGE	FACTORY RESET	
H TOTAL	TECH SUPPORT			
V TOTAL	WORK TIME			
H POS	LOCK FRONT PANEL			
V POS	LICENSE SETUP			
H SIZE	HOT BACKUP			
V SIZE	DELAY RECALL			
RESET				



3.3 Use the Menu

Use the menu system for convenient and intuitive operation. GX4pro TST display shows the menu items. The TST display will show the default state when the menu is not in use, or the operation has timed out. Using the **[** MENU **]** button and rotary knob in the front panel, the TST display will show the corresponding menus according to user selections.

3.3.1 LED Configuration

Image Control One is installed with SubitoNX[™] Quatro Sender Module or other universal sender card. Here is the led configuration sub-menu.

1. QUICK CONNECT

>QUICK CONNECT	>>
ADVANCED	>>
CONFIG FILE	>>

1.1 SEND CARD SET



CHOOSE CABLE: choose the output LAN port on the Sender, there are 4 ports available.

X,Y : the horizontal and vertical position of the display that the Sender card control the on LED screen.

One port of SubitoNX Sender can control 650K pixels. If a LED screen is under 650K pixels.

X,Y can be 0.

X maximum 1920

Y maximum 1080

SAVE SENDER CARD: save the X,Y setting to sender card.

RESET SEND CARD: reset sender card if parameters set above is not proper.



1.2 RECEIVE CARD SET



CHOOSE CABLE: choose the output LAN port on the Sender. There are 4 ports available.

HORIZONTAL CARD: how many receive cards needed to receive the data that the chosen sender port offer.

WIDTH: width of each led cabinet

HEIGHT:height of each led cabinet

HOR OFFSET: horizontal offset, -1-4095

VER OFFSET: vertical offset,-1-4095

CONNECT TYPE: the connection type of led cabinet.

There are 8 types available .

SAVE RECEIVER CARD: save setting above to receiver card.

1.3 RESET ALL CARD: reset all sender card and receiver card.

2. ADVANCED



2.1 COLOR TEMP

>RED	255
GREEN	255
BLUE	255
SAVE TO SEND CARD	

RED,GREEN,BLUE: value range from 0 to 255 SAVE TO SENDER CARD: save above setting to sender card



 $\ensuremath{\mathbb{C}}$ Xiamen RGBlink Science & Technology Co., Ltd.

3. CONFIG FILE



Users can load LED configuration files from LED manufacturers to the Image Control One devices by XTOOL. There are 15 manufacturers items in the sub-menu and each manufacture can store 16 files. 240 files in total allow to be loaded.

3.3.2 Out Bright

Output brightness to adjust the brightness of LED screen, value ranging from 0-255

3.3.3 Input

1. INPUT INFO

Show the current input format and resolution

INPUT INFO	>>
SIZING ADJUST	>>
USB CONTROL	>>
VGA ADJUST	>>
ADC AJUST	>>
SDI ADJUST	>>
EDID MANAGE	>>
VGA TYPE	VGA
DVI4 In1	NO EXT

2. SIZING ADJUST

H SIZE V SIZE H POS	1024 768 0
V POS RESET SIZE	0
MASK TOP MASK BOTTOM	>>
MASK LEFT	>>





H SIZE:set the horizontal pixels of input image to zoom or scale the input signal

- V SIZE:Set the vertical pixels of input image to zoom or scale the input signal
- H POS:set the horizontal position of image
- V POS:set the horizontal position of image

RESET SIZE: if the size is not proper, turn knob to RESET SIZE and press knob

MASK TOP:crop the top of image

MASK BOTTOM:crop the bottom of image

MASK LEFT:crop the left part of image

MASK RIGHT:crop the right part of image

RESET MASK: If the crop not proper, turn knob to RESET MASK and press knob.

3. VGA ADJUST

Non-standard VGA input signal can cause the input image shifting or not in full screen, therefore, users need to adjust VGA input as follows:

After selecting <AUTO AJUST> the device will automatically adjust the H POS,V POS, CLOCK and PHASE to make input image no shifting and full screen.

H POS	0
V POS	0
CLOCK	0
PHASE	0
>AUTO ADJUST	

Note: If one <AUTO AJUST> cannot meet the needs, users can do <AUTO AJUST> many times. The system can automatically save the ADJUST parameter. Users can also go to <AUTO AJUST> by pressing [VGA] button for 10s.

4. ADC ADJUST



AUTO ADUST: YES <OK>,NO <MENU> RESET: YES <OK>,NO <MENU>



© Xiamen RGBlink Science & Technology Co., Ltd.

5. SDI ADJUT

H POS	127
V POS	127
ANTI ALIAS	STEP_0
RESET	

Image Control One with SDI optional module come with SDI ADJUST in the menu.

6. EDID MANAGE

DESTINATION	HDMI
SOURCE	RGB DVI

DESTINATION: DVI or HDMI SOURCE: RGB DVI, RGB HDMI, FOLLOW, CUSTOM

CUSTOMIZE:		
>1920x1080@60		

CUSTOM EDID

Customize resolution for EDID

7. VGA TYPE

Choose signal type for VGA button. VGA or YPbPr.

8. DVI(4 In 1)

Image Control One with optional DVI module installed comes with such signal types as VGA, DVI, CVBS, YPbPr. It is offered to users to choose the signal type through the DVI connector which is compatible with VGA, DVI, CVBS, YPbPr via adapter.

3.3.4 Output

OUTPUT INFO OUTPUT FORMAT OUTPUT ADJUST SCREEN	>> >> >> >>
RATIO PICTURE TEXT OVERLAY DISPLAY MODE	NORMAL >> >> >>
GAMMA	LINEAR



 $\ensuremath{\mathbb{C}}$ Xiamen RGBlink Science & Technology Co., Ltd.

1. OUTPUT INFO

show current input information

>1920x1080@60 DVI MODE DVI BITS 8 BIT COLOR SPACE IMAGE	
DE	OFF
DE H POS	185
DE V POS	41
DE H SIZE	1920
DE V SIZE	1080
H POLARIRY	POS
V POLARITY	POS

2. OUTPUT FORMAT

>STANDARD	>>
CUSTOMIZE	>>

STANDARD: standard output resolution, 26 types available to choose from 720x480i@60 to 2560x816@60 CUSTOMIZE: custom resolution



Turn the knob to resolution line and press the knob ">" (arrow)change to "*" (star) put in the numbers for width, then press the knob to confirm the number.

Put in the numbers for height and frame rate in the same way.

Note: The number buttons lighting up indicate that users can use button to key in numbers.

3. OUTPUT ADJUST

DVI MODE	DVI
BITS	8 BIT
COLOR SPACE	IMAGE
DE ADJUST	>>

DVI MODE: DIV or HDMI BITS: DVI 8bit ,HDMI 8/10/12 bit COLOR SPACE: IMAGE or VIDEO



DE ADJUST

>DE	OFF
H POS	185
V POS	41
H SIZE	1920
V SIZE	1080
H POLARITY	POS
V POLARITY	POS

DE: ON or OFF

H POS: horizontal position, value from 0 to 1920

V POS: vertical position, value form 0 to 1080

H POLARITY: horizontal polarity, POS (positive) or NEG (negative)

V POLARITY:vertical polarity,

POS (positive) or NEG (negative)

RESET: reset above setting if not proper

4. SCREEN

H POS	185
V POS	41
H SIZE	1920
V SIZE	1080
MODE	FULL SIZE
RESET	

The setting of <SCREEN> is based on the resolution of the LED screen,applicable under single picture mode. For example to display picture on a LED screen with resolution 1408x832, first of all, a resolution close to or bigger than 1408x832 shall be selected. In this case, 1440x900 or resolution above will be proper choice. The closer to the LED screen resolution, the better the display will be.

H SIZE:horizontal pixels, turn the knob or use the digital button to input 1408.

V SIZE:vertical pixels, turn the knob or use the digital button to input 832.

H POS:horizontal position, default 0, set the value as the way of H SIZE and V SIZE.

V POS:vertical position, default 0, set the value as the way of H SIZE and V SIZE.

MODE-- Mode option, select SCREEN SIZE.

RESET: If image quality distorts by improper operation, it can be recover by reset.





5. RATIO

NORMAL, 16:9, 4:3

6. PICTURE

BRIGHTNESS CONTRAST RED	50 55 50
GREEN	50
BLUE	50
RESET	

Adjust the brightness, contrast and color for picture.

7. TEXT OVERLAY

Text overlay function is to add subtitle on output image, more often used on such fields as live broadcasting, live concert, live commentary, and advertisement.

Before text overlay, the subtitle input channel need to be ensured, e.g subtitle input channel VGA

And the overlayed channel need to be decided, e.g overlay text on DVI channel.

Set as follows:

Push 【VGA】 to check VGA input, LCD shows the VGA input.

- Push 【DVI】 to check DVI input, LCD shows the DVI input.
- Push 【PIP】, make sure VAG is the small picture and DVI the big picture,
- if not, turn the <SWAP PICTURE> "ON" in 【PIP】 menu.

PIP	ON
LAYOUT	PIP L+B
>SWAP PICTURE	ON
ALPHA	0

Select <SELECT> in 【PIP】 menu, push knob turn Knob to select"IMAGE B", Push <SCALE> to set the size and position of "IMAGE B" which the VGA picture in this case.

LAYOUT	PIP L+B
SWAP PICTURE	ON
ALPHA	0
>SELECT	IMAGE B



 $\ensuremath{\mathbb{C}}$ Xiamen RGBlink Science & Technology Co., Ltd.

If there is black rim on top, bottom, left or right of the VGA picture, use <MASK TOP>,<MASK BOTTOM>,<MASK LEFT><MASK RIGHT> to crop the black rim.

>H SIZE	>>
V SIZE	>>
H POS	>>
V POS	>>

Push 【MENU】, select<OUTPUT>, push knob;

Select <TEXT OVERLAY>, push knob and enter <TEXT OVERLAY> menu as follows:

>TEXT OVERLAY	ON
PRESET	WhOnBk1
BLEND MODE	MODE1
BLEND LEVEL	12

Select <PRESET>Push knob and turn the knob to "WhOnBk1" or "WhOnBk2" and Push knob again Note:TEXT OVERLAY only support monochrome subtitles.

>PRESET	WhOnBk1
BLEND MODE	MODE1
BLEND LEVEL	12
STAND	ABOVE

PRESET:User, WhONBk1 (white on black), WhONBk2 (white on black), BkOnWh1(black on white), BkOnWh2(black on white), GrnOnBk1 (green on black), GrnOnBk2 (green on black), GrnOnWh1 (green on white)1, GrnOnWh2(green on white), RedOnBk1 (red on black), RedOnBk2 (red on black), RedOnWh1 (red on white), RedOnWh2(red on white)

BLEND MODE:MODE 1 or MODE2 BLEND LEVEL:0-15 STAND (standard):BELOW or ABOVE AND/OR :choose "and" or "or" RED,GREEN,BLUE:value from 0 to 255

8. DISPLAY MODE

>MODE	LIVE IMAGE
TEST PATTERN	>>
SOLID COLOR	>>

MODE: BLACK OUT, LIVE IMAGE, FREEZE IMAGE, SOLID COLOR, TEST PATTERN.

TEST PATTERN	66
AUTO SWITCH	ON
HOR STEP	64
VER STEP	64

TEST PATTERN:Value 0-66 AUTO SWITCH: ON or OFF HOR STEP:horizontal color graduation value 0-64 VER STEP:vertical color graduation value 0-64



COLOR:WHITE, BLUE, GREEN, RED. SOLID COLOR

COLOR	
RED	255
GREEN	255
BLUE	255

RED, GREEN, BLUE: value 0-255

9. GAMMA

LINEAR, sRGB, -1.2, 1.2, -1.4, 1.4, -1.6, 1.6

3.3.5 Transition

Transition is used to set the switching mode between different input sources.

>MODE	FADE
DURATION	0.5S
ALPHA	16
DEINTERLACE	ON
IMAGE EHANCE	OFF
>TAKE	ON

MODE: Special effects switching modes, including FADE, CUT, WIPE SOUARE IN, WIPE SOUARE OUT, WIPE TOP LIEFT IN, WIPE TOP LIEFT OUT, WIPE TOP RIGHT IN, WIPE TOP RIGHT OUT, WIPE BOTTOM LEFT IN, WIPE BOTTOM LEFT OUT, WIPE BOTTOM RIGHT IN, WIPE BOTTOM LEFT OUT, WIPE LEFT IN, WIPE LEFT OUT, WIPE RIGHT IN, WIPE RIGHT OUT, WIPE TOP IN, WIPE TOP OUT, WIPE BOTTOM IN and WIPE BOTTOM OUT

DURATION:set the transition time ranging from 0.0 to 1.0 S

ALPHA:set the image transparency ranging from 0 to 16

DEINTERLACE:select ON or OFF to enable or shut down the deinterlacing function

IMAGE ENHANCE: image enhancement function, for image edge sharpening, color reduction and image scaling.

TAKE: Select ON or keep pressing 【TAKE】 button 3s to enable the function. The selected input signal will be switched to output as the TRANSITION set.

3.3.6 Audio

FF
59
Α
IAL



© Xiamen RGBlink Science & Technology Co., Ltd.

MUTE:select ON or OFF

Volume:adjustment range from 0 to 100

Users can also adjust volume without entering AUDIO menu. Rotate the knob anytime the LCD screen shows the main interface.

AUDIO IN:select the source of the input audio from IMAGE A or IMAGE B

HDMI:select internal or external audio for HMDI input

3.3.7 Split

Image Control One can be used in multiple cascade mode to finish split. When do cascade, connect the signals to the signal distributor first, and then connect from the outputs of the signal distributor to each input of Image Control One. User can also do cascade via HDMI LOOP port.

>SPLIT	ON
H TOTAL	1920
V TOTAL	1080
H POS	0
V POS	0
>H SIZE	1920
V SIZE	1080
RESET	

H TOTAL:set the total horizontal pixels of the LED screen, maximum 65535

V TOTAL:set the total vertical pixels of the LED screen, maximum 65535

H POS: select the total number of horizontal screens

V POS: select the total number of vertical screens

H SIZE:set the horizontal pixels this device will provide, maximum 4096

V SIZE: set the vertical pixels this device will provide, maximum 4096

Reset: If image quality distorts by improper operation, it can be recover by reset.

When doing equal splitting, set H SIZE and V SIZE of each device with same resolution, and then set H POS and V POS of each device correspondingly. When doing unequal splitting, set and save H SIZE and V SIZE of each device according to actual needs.

3.3.8 System

1. SYSTEM INFO

SYSTEM INFO	>>
TECH SUPPORT	>>
WORK TIME	>>
LOCK FRONT PANEL	>>

Show flowing information MCU VERSION, VIDEO VERSION, EXT VERSION, SN



2. TECH SUPPORT



3. WORK TIME

WORK TIME	>>
TOTAL TIME	>>
BOOT TIMES	10

WORK TIME: the consistent working time since latest boot up. TOTLAL TIME: the accumulative working time since the first boot up. BOOT TIMES: the total boot up times up to now.

4. LOCK FRONT PANEL

YES <OK>, NO <MENU>

After the panel is locked, keep pressing MENU for 3 S to release the panel.

5. LICENSE SET UP

ENETER PASSWORD 090721 and set new password for other users.

6. HOT BACKUP

Hot Backup	ON
Backup_1	VGA
Backup_2	DVI
Backup 3	CVBS
Backup_4	HDMI
Backup_4 Backup_5	HDMI OFF



HOT BACKUP: ON or OFF HOT BACKUP_1,2,3,4,5, Chose Hot Backup On and choose one input source for the each backup. Up to 5 backups can be set

7. DELAY RECALL

Value range from 0 to 255S

3.3.9 Language

To switch langue here. English or Chinese available. Or Keep pressing MENU and SCALE button for 3 S to switch language.

3.3.10 Factory Reset



3.4 Shortcut Buttons

Image Control One comes with shortcut buttons to enter the sub-menu of certain features. Here are details of some quick buttons.

3.4.1 【TAKE】 Button

When Image Control One power on, system default HDMI input signal.

To switch signal, press CVBS,VGA,DVI or SDI. For example, to switch to CVBS, push VGA button and the button flashes.

TAKE MODE allow users to switch inputs with transition effect

To Enable TAKE mode , Keep pressing the button for 3s and the TAKE MODE is ON.

The LCD screen shows the info below for 2S





Then push TAKE button again. VGA signal will be switched to LED screen with set transition effect.



© Xiamen RGBlink Science & Technology Co., Ltd.

3.4.2 **[PIP]** Button

PIP mode cann't be enabled unless TAKE MODE is OFF.

 $Push_{DSK}^{PIP}$ button and button light is on. LCD shows the <PIP> menu.

PIP		ON
LAYOUT	PIP	L+B
SWAP PICTURE		ON
ALPHA		0

LAYOUT

There are 7 layouts available in the menu. PIP L+T, PIP R+T, PIP L+B, PIP R+B, PIP CENTER, PBP L+R and PBP T+B. Here are 3 examples



SWAP IMAGE

Select on or off to switch the main picture and secondary picture (the small one).

ALPHA

Image transparency setting, the adjustment range is 0 to 16.

SECLECT

Select IMAGE A or IMAGE B.

3.4.3 **[SCALE]** Button

To scale the output image, users can press [SCALE] button and set the parameters by turning knob or pressing

numeral buttons.

After user press 【SCALE】, LCD shows the menu items as follows:

H SIZE	1920
V SIZE	1080
H POS	0
V POS	0

H SIZE: set the horizontal pixels of output image

V SIZE: set the vertical pixels of output image



© Xiamen RGBlink Science & Technology Co., Ltd.

Ph: +86 0592 5771197 | support@rgblink.com | www.rgblink.com

H POS: set the horizontal position of image

V POS: set the horizontal position of image

RESET: If operation is not proper, turn knob to <RESET> and start over.

3.4.4 【SAVE】 Button

Push the [SAVE] button, the button light is on, and enable the SAVE function.

LCD shows [SAVE] instruction info to assist users complete operation. Meanwhile, part of numeral buttons 0~9 lights are on and parts flash. Buttons with lights on are empty, flashing buttons are used. LCD shows as below.



Saving to flashing positions will overwrite previously saved settings. For example, button 1 is flashing, after pressing button 1, LCD shows.



Push knob to confirm, 【MENU】 to cancel. Up to 10 groups of SAVE can be done from SAVE1 to SAVE 10

3.4.5 【LOAD】 Button

Push **[LOAD]** LCD shows the instruction information to assist users complete LOAD operation.

Meanwhile, among numeral buttons 0-9, some buttons lights are on, some flash and perhaps some lights go off. Buttons with light on indicate the <SAVE> ready to load, flash indicate the <SAVE> is currently loaded, light off indicate no <SAVE> to load. For example button 1 light is on, press button 1 to load <SAVE1> LCD shows below:



Push 【MENU】 to exit LOAD, the button lights go out.



Chapter 4 Ordering Codes

4.1 Product

820-1004-05-0 GX4

GX4pro

4.2 Options

190-0001-02-1	Single VGA Input Module
190-0001-04-1	Single DVI Input Module
190-0001-06-1	Single HDMI Input/Loop Module
190-0001-07-1	Single 3G SDI Input/Loop Module
190-0001-09-1	Single CVBSInput/Backup Module
190-0001-32-0	EXT Module
880-0033-01-0	SubitoNX Quatro Sender Module
190-0004-01-0	Single USB Input/Backup Module
190-0004-02-0	Single DVI Input Module
190-0004-04-0	Single 3G SDI Input/Loop Module
190-0004-05-0	Single HDBaseT Input Module
190-0004-08-0	Single SDI Input/Loop Module
190-0001-13-2	Single HDMI Input Module
190-0004-06-0	EXT Module

Chapter 5 Support

5.1 Contact Us

www.rgblink.com



China Regional Sales & Support RGBlink **Beijing Region Europe Regional** Headquarters Office Sales & Support Beijing, China Xiamen, China Shenzhen, China Eindhoven, Holland 11th Floor Baiwang Building 5318 Shahe West Road Room 601A, No. 37-3 Building 8, 25 Qixiao Road Flight Forum Eindhoven Banshang community, Building 3, Xinke Plaza, Torch Hi-Tech Industrial Development Zone, Xiamen, China Shahe Town Changping 5657 DW Baimang, Nanshan China +86-592-577-1197 +86-755 2153 5149 +010- 8577 7286 +31 (040) 202 71 83



Chapter 6 Appendix

6.1 Specification

CVBS Input (Star	ıdard)					
Number of	1					
Inputs						
Connector	BNC					
Interface						
Appearance						
	CVBS IN					
Supported	PAL/NTSC					
Standard						
Signal Level	1Vpp±3db (0.7V Video+0.3v Sync) 75 ohm					
Supported	480i 576i					
Resolution						
VGA Input (Stand	dard)					
Number of	1					
Inputs						
Connector	DB15					
Supported	VGA-UXGA					
Standard						
Interface						
Appearance						
	VGA IN					
Supported	VESA 800×600@60 1024×768@60 1280×1024@60 1440×900@60 1600×1200@60					
Resolution						
HDMI Input (Sta	ndard)					
Number of	2 (1 IN 1 LOOP)					
Connectors						
Connector	HDMI-A					
Interface						
Appearance						
	HDMI IN HDMI LOOP					
Supported	SMPTE 625/25/50 PAL, 525/29.97/59.94 NTSC,					
Resolution	720p50/59.94/60 1080i50/59.94/60 1080P50/59.94/60					
	VESA 800×600@60 1024×768@60 1280×768@60 1280×1024@60 1600×1200@60					
	1920×1080@60					
Circulture 1						
Signal Level	TMDS pwl, single pixel input,165MHz band pixels					



Supported	HDMI 1.3
Standard	
DVI Input (Sta	indard)
Number of	1
Inputs	
Connector	DVI-I
Interface	
Appearance	
Supported	SMPTE 480i NTSC,576i PAL, 720p50/59.94/60
Resolution	1080i50/59.94/60 1080p50/59.94/60
	VESA 800×600@60 1024×768@60 1280×768@60 1280×1024@60 1600×1200@60 1920×1080@60
Supported	Single Link DVI
Standard	
3G-SDI Input	(Optional)
Number of	2 (1 IN 1 LOOP)
Connectors	
Connector	BNC
Interface	SDI IN SDI LOOP
Appearance	
Data Rate	2.97Gb/s 2.97/1.001Gb/s 1.485Gb/s 1.485/1.001Gb/s 270Mb/s
Supported	SMPTE 480i NTSC,576i PAL, 720p50/59.94/60
Resolution	1080i50/59.94/60 1080p50/59.94/60
Supported	SMPTE 425M (Level A & B) SMPTE 424M SMPTE 292M SMPTE 259M-C DVB-ASI
Standard	

HDBaseT Input	(Optional)	
Number of	1	
Connectors		
Connector	RJ45	
Supported	SMPTE	480i NTSC,576i PAL, 720p50/59.94/60
Resolution		1080i50/59.94/60 1080p50/59.94/60
	VESA	800×600@60 1024×768@60 1280×768@60 1280×1024@60 1600×1200@60
		1920×1080@60



Number of	2						
Outputs							
Connector	DVI-I						
Interface							
Appearance	Ó.	# IO					
	DVI2 OU	r					
	O DVI1 OU	*)0					
Supported	SMPTE 62	SMPTE 625/25/50 PAL, 525/29.97/59.94 NTSC,					
Resolution	72	0p50/59.94/6	50 1080i50/59.94/60 1080P50/59.94/60				
	12	80×720@23.9	98 1280×720@24 1280×720@25 1280×720@29.97				
	12	80×720@30	1920×1080@23.98 1920×1080@24 1920×1080@25				
	19	20×1080@29	.97 1920×1080@30				
	VESA 80	0×600@60	1024×768@60 1024×768@75 1280×720@60 1280×720@50				
	12	80×768@60	1280×800@60 1280×1024@60 1360×768@60 1366×768@60				
	14	00×1050@60	1440×900@60 1600×1200@60 1680×1050@60				
	19	20×1080@60	1920×1080@50 1920×1200@60 2048×1152@60 2560×812@60				
	25	60×816@60					
SubitoNX Quatro	o Sender Modu	le (Optiona	11)				
Number of	4						
Outputs							
Connector	RJ45						
Interface Appearance							
Performance	Each Port						
	Capacity		2310000 pixels				
	Horizontal F	Range	3840 pixels				
	Vertical Ran	ge	1920 pixels				
Features							
Grey	10 bit						
Processing							
Frame Rate	2						
Delay							
EDID	Yes						
Management							
Accessories and O	perating Condit	ion					
Communication	RJ11/RS232						
Input Voltage	AC100-240V/						



Working	0°C~45°C
Temperature	
Working Humidity	10%~85%
Warranty	3 Years

6.2 Load LED Configuration File

You can load LED configuration file from XPOSE software.Install the software in your control computer firstly. 1. Click and select 【GX4pro】

							5	System Setting		
D	System Info		Layer Manage	ment				Display Setting		
							ON C			
			Find Device				Check All	Network Info		d in the second s
	Keyboard Hanager		FLEXE		FLEX32	FLEX411	FLExpro8			d in the second s
eg		Keyboard	GX4		🔲 X1-G		Subito54			
	Authorization Setting		G101		NK \$2/300					d in the second s
			■ X2		37	3114	x20			d in the second s
		Logout	D1K	D 4	DS DS					
Q	Communication Setting	Search 🔲 Direct	■ V34							
\sim	Serial Port		Q2	Q4	Q4L	QLG	Q16pro			
	Ethernet Connection		EMS							d in the second s
	Both Are Chosen	OK D	1 0							
0	Prompt Message									
9		00								d in the second s
		0N 🔵								
۳										
										d in the second s
88										
00										
										d in the second s
										d in the second s
										d in the second s
										d in the second s
										d in the second s
										d in the second s
										ļļļ
-										*
•										

2. Click the icon and tick GX4pro in <All Devices>and<Chosen Devices>,the rear panel of GX4pro can be seen in the interface.



 Click the LAN port to adjust the parameters. Out Bright 0~255
 Set position, resolution and 3D



 $\ensuremath{\mathbb{C}}$ Xiamen RGBlink Science & Technology Co., Ltd.

< Quatro	Library		>
Basic Parameter			
Out Bright	•	1	
Postion			
Start X	0		
Start Y	0		
Width	0		
Height	0		
Fre	0		
	Set		
3D Set			
3D USE	Switch Frame		
Window Width	0		
Window Height	0		

Library: There are 3 kinds of method to adjust the screen parameters

Method 1:Select the saved files In XPOSE.

File Type:select Local;

Product Series/Library File:select according to your needs

Click **[**Load **]** ,and the file will be imported into the software.

Click [Send to RCard] to view the real-time change in LED screen; click [Save to RCard] to ensure the data without loss.



Method 2:Import the file from manufacture to XPOSE.

File Type:select Customize

Click 【Choose File】, select the file from your computer and then click 【Load】 to import.



© Xiamen RGBlink Science & Technology Co., Ltd.

۲	Quatro	Library
File	Туре	Customize
		Choose File
File	Information	
File	Path	file:///C:/Users/Administrator/Deskt op/XPOSE20_2.0.5.3_GX4_20210816 /XPOSE20_2.0.5.3_IC_20210816/XPO SE/Subito/Common/Series1/0415.rcf ile
File	Name	0415.rcfile
		Load
		Send to RCard
		Save to RCard
Recv	card Param	
		Parameters Set

Method 3 : If the saved files could not meed your needs, you can click 【Parameter Set】 to adjust the parameters. Click 【Parameters Set】 to open adjustment page

<	Quatro	Library	>
File T	уре	Local	
Manu	facturer	1.Common	
Produ	ict Series	1.Series1	
Librar	ry File	1.0415.rcfile 🔻	
File I	nformation		
File P	'ath	file:///C:/Users/Administrati op/XPOSE20_2.0.5.3_GX4_2 /XPOSE20_2.0.5.3_IC_20210 SE/Subito/Common/Serles1/ ile	0210816 816/XPO
File N	lame	0415.rcfile	
		Load	
		Send to RCard	
		Save to RCard	
	ard Param	neters	
		Parameters Set	

1. Click [Device manage] -- [Add device], select NX 600, and click [OK].

Equipment type	NX 300	~	
	NX 500 NX 600		
Communication	CS2 CS4 S2-BOX	O Network	O Bridge
Serial port No.	S4-BOX GX2L GX4L	2) ~	
Baud rate	NV8 NV16 D20		
设备号	设备型号	设备版本	


Select the Serial Port to connect, and click 【Apply】.

Device Manage	x
Add Delete	Update list
Serial port priority connection	
Remember current communication port	Apply OK Cancel

please click \bigcirc to connect the device .

RGBLink 1.5		Setu	p (<u>S</u>)	tools (<u>T</u>)	Test (D)	Help (H)	
een configuration	Brightness Device man	Correction		Monitor	Multi-fun	card De	wice manage
Device name	De	vice version	No.	D	evice port	Con	nect Stat
🗠 NX 600		V1.0	0		COM3	С	onnect
2 10100		*IN	U.S.				

2. Click [Screen Configuration] to enter Sending Card interface.

Please ensure that the **resolution** of sending card should be the consistent with that of your computer. After setting the sending card, it is necessary to click **(**Save to the sending card **)**, otherwise the previous setting will be lost after power off and restarting.

Input source configuration - Source signal		Network port me	nagement		Current send	device AlDevice	•
source number	s bit 🔹	Jevice(Port)	X Start	Y Start	Width	Height	
resolution	1920 ×1080 🔹	1	0	0	0	0	
frame rate	unknown Hz	2	0	0	0	0	
Custom resolution	1920 x 1080						
Custom frequency	60.00 Hz						
	application						
nter the starting point Settin	ngs						
X starting point	0						
Y starting	0						
D function Settings							
enable 3 d							

- 3. Click 【Receiving Card】 to enter the interface as shown in the left figure.
- 4. Click 【Smart Settings】 to set receiving card.



Module information						
Type of chip	General	- Sca	nning mode Full-color r	eal pixel 32 scan 32		Module information
box setting						
Width (points)	256	<=370	Output mode	Normal •]	heterotype box
Height (points)	128	<=512	Data group number	Conventional 16 gr •	-	
Cascade directio	Right to left	•		Data group exchange		abriormity box
performance/effects Set	tings					
refresh frequency	120			Auto 🔻	Hz E	Synchronous refresh
DCLK frequency (shift	8.3	 MHZ 	DCLK duty ratio	50	%	
DCLK phase (shift clock)	7	• %	grayscale series	Refresh(65536) -	level	
line blanking time	300	nanosec	low ash effect	high refresh-low ligi 🔻	1	
End time of afterglow	24	(1 ~ 43)				
line feed time	5	(0 ~ 23)				
Brightness efficiency (i	nduding blanking) : 3	5.5%				more Settings

5. Chip selection:select the chip for the corresponding module.

Data Type:It is generally to choose parallel driver for common modules by default (If you would like to customize some modules needed to select serial data, please contact with our company.

Module Type: If width of single module is 16, then choose [Regular light board]. If not, then choose [Profiled lamp board(with taps)].

the actual number of: the width of single module

Number of data rows: the height of single module

Number of data line: It can be viewed according to the number of RBG groups defined by the module interface.

Line decoding mode:138 decoding,etc

Number of data sets:Conventional and Serial can be selected.

Cascade direction:Left to right/Right to left/Top to bottom/Bottom to top

module chip		
Lamp board chip	General chip selection	
Data Type	Parallel drive 🔻	
module information		
Module type	Regular light board Profiled lamp board (with taps)	
the actual number of	64 number of data rows (Y) 32	
Number of data line	1	
line decoding mode	138 decoding	
Number of data sets	Conventional 16 group 🔻	
Cascade direction	Right to left	

6. Users can remove the \checkmark of **[** state changes automatically **]**, and click 1/2/3/4 to change the display state according to the observation of the LED screen.

For example, click [1] and observe the color of LED screen, and select [red] if the LED screen shows red. After all 4 states being done, click [next]



	e changes automatically nge.	, please select the corresponding displ	ay state according to the
play o	thange		
) 1	Display state 1	red	•
) 2	Display status 2	green	. •
) 3	Display status 3	blue	•
4	Display state 4	black	¥

7. Select [horizontal or vertical lines] according to the actual bright line direction of display screen.

Number of bright rows on display: according to the LED screen

Number of spaced rows: When only one line is lit on the screen, the number of rows between must be selected.

🥪 Intelligent setup guide6		x
Bright line direction of display screer	ı	
o horizontal	🔘 vertical lines	
Number of bright rows on display		
1	▼ trace point	J1 🔹
Number of spaced rows (with one br	right row)	A
1	•	
Prompt When only one line is lit on the scre selected.	en, the number of rows between mu	ust be
		i i
on the step no	ext	cancel

8. Observe the position of the bright spot on the first module of the LED screen, and click the corresponding grid. If you make a mistake, click 【 back 】 to the last step or 【 reset 】 to restart.

If you select **[** Profiled lamp board(with taps) **]** in 5th step, you need to click blank spots. Observe the first module, and click **[** unbright spot(blank spot) **]** if no flash spot appears.

After the settings, a prompt will pop up. Click **(**OK**)** and then click **(**Finish**)** to confirm.

34	-Sige	19 19 19	erner e	Alon .			ы	dk.		reset			urbe	94 H 350	104 (BA 12)	est.	total e	n¢ty (onts															24	port r Tab	outing Is	Exp	ort roui table	ting ,	in the	step	iónió	6.66	CR	ncel
	3		2	3	4	5	6	1	8	9.	10	11	12	13	14	15	16	12	18	19	20	21	22	23	24	25	26	27	28	29	30	35	32	33	34	35	-36	37	38	29	43	41	42	43	44
1																																													
2																																													
3																																													
i.																																													
5																																													
6																																													
,	F																																												
0																																													
1																																													
2																																													
à	1																																												

9. After [Smart Settings], it will return to [Receiving card] interface and set a new parameters for receiving cards. (1) Fill in the total Width/Height of box.

There is no need to adjust other parameters if the image of the single receiving card is normal.

(2) It is recommended to change 【grayscale series】 and 【low ash effect】 to change the refresh rate.

③**Send to receive card:**Each time you change the parameters, you can click 【Send to receive card】 and observe the change of the screen.

(4) Save to the receive card: After debugging, click [Save to the receiving card] and the data will not be lost after power off and restart.



Type of chip	General	+ Scann	ing mode Full-color real	pixel 32 scan 32	Module information	
box setting Width (points)	256	⇒ <=370	Output mode	iormal 👻	heterotype box	
Height (points)	128	=512	Data group umber		E meetacype box	
Cascade direction	Right to left	•		Data group exchange	abnormity box	
performance/effects Sett	ings					
refresh frequency	120	✓ HZ	A	uto 👻 Hz	Synchronous refresh	
DCLK frequency (shift	8.3	▼ MHZ	DCLK duty ratio 5	0 %	\sim	
DCLK phase (shift clock)	7	• %	grayscale series	efresh(65536) 🔹 leve		
line blanking time	300	nanosec	low ash effect h	igh refresh-low ligi 💌		
End time of afterglow	24	(1~43)			\sim	
line feed time	5	(0 ~ 23)				
Brightness efficiency (in					more Settings	

Upgrade

1. Click [Setup] -- [Hardware upgrade].



2. Type in password 【admin】 or 168.

🎯 Hardware upgrade	x
Please enter the passwor	a
sure can	cel

Send Card Upgrade:

- 1 Select [Send Card]



© Xiamen RGBlink Science & Technology Co., Ltd. Ph: +86 0592 5771197 | support@rgblink.com | www.rgblink.com

- 3 Load corresponding send card
- ④ Click 【upgrade】

	th	,Desktop\A5	16_CS2017_101D_2021-0	4-12-192018.updata			oad
						(3)
rogram read	back (curren	ly only supports	video scan card 'receive o	ard" read back)			_
Program pa	th	C:\Users\Admi	nistrator\Desktop\XPOSE2	4		rea	d back
						9	2
ardware ver	sion informati	00				(4
Video scar			าก				/iew
							~
NetPort	Card No.	Version No.	Card Mode	Program Name	Time	Card type (2)
NetPort 1	Card No. 1	Version No. V1.0	Card Mode SubitoNX 300	Program Name	Time	Card type (2
				Program Name	Time	Card type (2
				Program Name	Time	Card type (2)
				Program Name	Time	Card type (2
				Program Name	Time	Card type (2
				Program Name	Time	Card type (2
				Program Name	Time	Card type (2
				Program Name	Time	Card type (2

Receive Card Upgrade:

- 1 Select [Receive Card]
- 2 View the version
- ${}^{\textcircled{3}}$ Load corresponding send card
- $(4)\$ Click ${\mbox{[upgrade]]}}$,do not unplug the serial port to prevent communication disconnection

rogram load Program pat	h A	sktop\A516_C52017_101D_2021-04-12-192018.updata	load
rogram read	back (currently or	/ supports video scan card 'receive card' read back)	
Program pat	h C:\	sers\Administrator\Desktop\XPOSE2\	read back
			(4)
	ion information		
Video captu	re card		view
card nu	The version	Card type	(2)
1	V1.0	SubitoNX L01	`

6.3 Terms & Definitions

•RCA: Connector used primarily in consumer AV equipment for both audio and video. The RCA connector was developed by the Radio Corporation of America.

•BNC: Stands for Bayonet Neill-Concelman. A cable connector used extensively in television (named for its inventors). A cylindrical bayonet connector that operates with a twist-locking motion .

•**CVBS**: CVBS or Composite video, is an analog video signal without audio. Most commonly CVBS is used for transmission of standard definition signals. In consumer applications the connector is typically RCA type, while in professional applications the connector is BNC type.

•YPbPr: Used to describe the colour space for progressive-scan. Otherwise known as component video.

•VGA: Video Graphics Array. VGA is an analog signal typically used on earlier computers. The signal is non-interlaced in



modes 1, 2, and 3 and interlaced when using in mode

•**DVI**: Digital Visual Interface. The digital video connectivity standard that was developed by DDWG (Digital Display Work Group). This connection standard offers two different connectors: one with 24 pins that handles digital video signals only, and one with 29 pins that handles both digital and analog video.

•SDI: Serial Digital Interface. Standard definition video is carried on this 270 Mbps data transfer rate. Video pixels are characterized with a 10-bit depth and 4:2:2 color quantization. Ancillary data is included on this interface and typically includes audio or other metadata. Up to sixteen audio channels can be transmitted. Audio is organised into blocks of 4 stereo pairs. Connector is BNC.

•HD-SDI: high-definition serial digital interface (HD-SDI), is standardized in SMPTE 292M this provides a nominal data rate of 1.485 Gbit/s.

• **3G-SDI**: standardized in SMPTE 424M, consists of a single 2.970 Gbit/s serial link that allows replacing dual link HD-SDI.

•6G-SDI: standardized in SMPTE ST-2081 released in 2015, 6Gbit/s bitrate and able to support 2160p@30.

•12G-SDI:standardized in SMPTE ST-2082 released in 2015, 12Gbit/s bitrate and able to support 2160p@60.

•U-SDI:Technology for transmitting large-volume 8K signals over a single cable. a signal interface called the ultra high definition signal/data interface (U-SDI) for transmitting 4K and 8K signals using a single optical cable. The interface was standardized as the SMPTE ST 2036-4.

•HDMI: High Definition Multimedia Interface: An interface used for the transmission of uncompressed high definition video, up to 8 channels of audio, and control signals, over a single cable.

•HDMI 1.3: released on June 22 2006, and increased the maximum TMDS clock to 340 MHz (10.2 Gbit/s). Support resolution 1920 × 1080 at 120 Hz or 2560 × 1440 at 60 Hz). It added support for 10 bpc, 12 bpc, and 16 bpc color depth (30, 36, and 48 bit/px), called deep color.

• HDMI 1.4: released on June 5, 2009, added support for 4096 × 2160 at 24 Hz, 3840 × 2160 at 24, 25, and 30 Hz, and 1920 × 1080 at 120 Hz. Compared to HDMI 1.3, 3 more features added which are HDMI Ethernet Channel (HEC), audio return channel (ARC),3D Over HDMI, a new Micro HDMI Connector, an expanded set of color spaces.

• HDMI 2.0, released on September 4, 2013 increases the maximum bandwidth to 18.0 Gbit/s. Other features of HDMI 2.0 include up to 32 audio channels, up to 1536 kHz audio sample frequency, the HE-AAC and DRA audio standards, improved 3D capability, and additional CEC functions.

• HDMI 2.0a: was released on April 8, 2015, and added support for High Dynamic Range (HDR) video with static metadata.

• HDMI 2.0b: was released March, 2016, support for HDR Video transport and extends the static metadata signaling to include Hybrid Log-Gamma (HLG).



• HDMI 2.1 : released on November 28, 2017. It adds support for higher resolutions and higher refresh rates, Dynamic HDR including 4K 120 Hz and 8K 120 Hz.

• **DisplayPort:** A VESA standard interface primarily for video, but also for audio, USB and other data. DisplayPort (orDP) is backwards compatible with HDMI, DVI and VGA.

• **DP 1.1:** was ratified on 2 April 2007, and version 1.1a was ratified on 11 January 2008. DisplayPort 1.1 allow a maximum bandwidth of 10.8 Gbit/s (8.64 Gbit/s data rate) over a standard 4-lane main link, enough to support 1920x1080@60Hz

• **DP 1.2:** introduced on 7 January 2010, effective bandwidth to 17.28 Gbit/s support increased resolutions, higher refresh rates, and greater color depth, maximum resolution 3840 × 2160@60Hz

• **DP 1.4:** publish on 1 Mar, 2016.overall transmission bandwidth 32.4 Gbit/s ,DisplayPort 1.4 adds support for Display Stream Compression 1.2 (DSC), DSC is a "visually lossless" encoding technique with up to a 3:1 compression ratio. Using DSC with HBR3 transmission rates, DisplayPort 1.4 can support 8K UHD (7680 × 4320) at 60 Hz or 4K UHD (3840 × 2160) at 120 Hz with 30 bit/px RGB color and HDR. 4K at 60 Hz 30 bit/px RGB/HDR can be achieved without the need for DSC.

•Multi-mode Fiber: Fibers that support many propagation paths or transverse modes are called multi-mode fibers, generally have a wider core diameter and are used for short-distance communication links and for applications where high power must be transmitted.

•Single-mode Fiber: Fiber that support a single mode are called single-mode fibers. Single-mode fibers are used for most communication links longer than 1,000 meters (3,300 ft).

•SFP: small form-factor pluggable, is a compact, hot-pluggable network interface module used for both telecommunication and data communications applications.

•optical fiber connector: terminates the end of an optical fiber, and enables quicker connection and disconnection than splicing. The connectors mechanically couple and align the cores of fibers so light can pass. 4 most common types of optical fiber connectors are SC, FC, LC,ST.

•SC:(Subscriber Connector), also known as the square connector was also created by the Japanese company – Nippon Telegraph and Telephone. SC is a push-pull coupling type of connector and has a 2.5mm diameter. Nowadays, it is used mostly in single mode fiber optic patch cords, analog, GBIC, and CATV. SC is one of the most popular options, as its simplicity in design comes along with great durability and affordable prices.

• LC: (Lucent Connector) is a small factor connector (uses only a 1.25mm ferrule diameter) that has a snap coupling mechanism. Because of its small dimensions, it is the perfect fit for high-density connections, XFP, SFP, and SFP+ transceivers.

• FC :(Ferrule Connector) is a screw type connector with a 2.5mm ferrule. FC is a round shaped threaded fiber optic connector, mostly used on Datacom, telecom, measurement equipment, single-mode laser.



• **ST:** (Straight Tip) was invented by AT&T and uses a bayonet mount along with a long spring-loaded ferrule to support the fiber.

• USB: Universal Serial Bus is a standard that was developed in the mid-1990s that defines cables, connectors and communication protocols. This technology is designed to allow a connection, communication and power supply for peripheral devices and computers.

• USB 1.1: Full–Bandwidth USB, specification was the first release to be widely adopted by the consumer market. This specification allowed for a maximum bandwidth of 12Mbps.

•USB 2.0:or Hi–Speed USB, specification made many improvements over USB 1.1. The main improvement was an increase in bandwidth to a maximum of 480Mbps.

• USB 3.2: Super Speed USB with 3 varieties of 3.2 Gen 1(original name USB 3.0), 3.2Gen 2(original name USB 3.1), 3.2 Gen 2x2 (original name USB 3.2) with speed up to 5Gbps,10Gbps,20Gbps respectively.

USB version and connectors figure:

	Type A	Туре В	Mini A	Mini	Micro-A	Micro-B	Туре С
				В			
USB 2.0				(100000		U CONTRACTOR	
USB 3.0						(fanne)	
USB 3.1&3.2							

•NTSC : The colour video standard used in North America and some other parts of the world created by the National Television Standards Committee in the 1950s. NTSC utilizes an interlaced video signals.

•PAL: Phase Alternate Line. A television standard in which the phase of the colour carrier is alternated from line to line. It takes four full images (8 fields) for the colour-to-horizontalimages (8 fields) for the colour-to-horizontal phase relationship to return to the reference point. This alternation helps cancel out phase errors. For this reason, the hue control is not needed on a PAL TV set. PAL, is widely used in needed on a PAL TV set. PAL, is widely used in Western Europe, Australia, Africa, the Middle East, and Micronesia. PAL uses 625-line, 50-field (25 fps) composite colour transmission system.

• SMPTE: Society of Motion image and Television Engineers. A global organization, based in the United States, that sets standards for baseband visual communications. This includes film as well as video and television standards.

•VESA: Video Electronics Standards Association. An organization facilitating computer graphics through standards.



•HDCP: High-bandwidth Digital Content Protection (HDCP) was developed by Intel Corporation an is in wide use for protection of video during transmission between devices.

•HDBaseT: A video standard for the transmission of uncompressed video (HDMI signals) and related features using Cat 5e/Cat6 cabling infrastructure.

•**ST2110:** A SMPTE developed standard, ST2110 describes how to send digital video over and IP networks. Video is transmitted uncompressed with audio and other data in a separate streams.

SMPTE2110 is intended principally for broadcast production and distribution facilities where quality and flexibility are more important.

•SDVoE: Software Defined Video over Ethernet (SDVoE) is a method for transmission, distribution and management AV signals using a TCP/IP Ethernet infrastructure for transport with low latency. SDVoE is commonly used in integration applications.

•Dante AV: The Dante protocol was developed for and widely adopted in audio systems for the transmission of uncompressed digital audio on IP based networks. The more recent Dante AV specification includes support for digital video.

•NDI: Network Device interface (NDI) is a software standard developed by NewTek to enable video-compatible products to communicate, deliver, and receive broadcast quality video in a high quality, low latency manner that is frame-accurate and suitable for switching in a live production environment over TCP (UDP) Ethernet based networks. NDI is commonly found in broadcastapplications.

•**RTMP:** Real-Time Messaging Protocol (RTMP) was initially a proprietary protocol developed by Macromedia (now Adobe) for streaming audio, video and data over the Internet, between a Flash player and a server.

•RTSP : The Real Time Streaming Protocol (RTSP) is a network control protocol designed for use in entertainment and communications systems to control streaming media servers. The protocol is used for establishing and controlling media sessions between end points.

•MPEG: Moving Picture Experts Group is a working group formed from ISO and IEC developing standards that allow audio/video digital compression and Transmission.

•H.264: Also known as AVC (Advanced Video Coding) or MPEG-4i is a common video compression standard. H.264 was standardized by the ITU-T Video Coding Experts Group (VCEG) together with the ISO/IEC JTC1 Moving Picture Experts Group (MPEG).

•H.265: Also known as HEVC (High Efficiency Video Coding)H.265 is the successor to the widely used H.264/AVC digital video coding standard. Developed under the auspices of ITU, resolutions up to 8192x4320 may be compressed.

•API: An Application Programming Interface (API) provides a predefined function which allows access capabilities and features or routines via a software or hardware, without accessing source code or understanding the details of inner



© Xiamen RGBlink Science & Technology Co., Ltd. Ph: +86 0592 5771197 | support@rgblink.com | www.rgblink.com working mechanism. An API call may execute a function and/or provide datafeedback/report.

•DMX512: The communication standard developed by USITT for entertainment and digital lighting systems. The wide adoption of the Digital Multiplex (DMX) protocol has seen the protocol used for a wide range of other devices including video controllers. DMX512 is delivered over cable of 2 twisted pairs with 5pin XLR cables for connection.

•ArtNet: An ethernet protocol based on TCP/IP protocol stack, mainly used in entertainment/events applications. Built on the DMX512 data format, ArtNet enables multiple "universes" of DMX512 to be transmitted using ethernet networks for transport.

•MIDI: MIDI is the abbreviation of Musical Instrument Digital Interface. As the name indicates the protocol was developed for communication between electronical musical instruments and latterly computers. MIDI instructions are triggers or commands sent over twisted pair cables, typically using 5pin DIN connectors.

•OSC: The principle of Open Sound Control (OSC) protocol is for networking sound synthesizers, computers, and multimedia devices for musical performance or show control. As with XML and JSON, the OSC protocol allows sharing data. OSC is transported via UDP packets between devices connected on an Ethernet.

•Brightness: Usually refers to the amount or intensity of video light produced on a screen without regard to colour. Sometimes called black level.

•Contrast Ratio: The ratio of the high light output level divided by the low light output level. In theory, the contrast ratio of the television system should be at least 100:1, if not 300:1. In reality, there are several limitations. Well-controlled viewing conditions should yield a practical contrast ratio of 30:1 to 50:1.

•Colour Temperature: The colour quality, expressed in degrees Kelvin (K), of a light source. The higher the colour temperature, the bluer the light. The lower the temperature, the redder the light. Benchmark colour temperature for the A/V industry include 5000°K, 6500°K, and 9000°K.

•Saturation: Chroma, Chroma gain. The intensity of the colour, or the extent to which a given colour in any image is free from white. The less white in a colour, the truer the colour or the greater its saturation. Saturation is the amount of pigment in a colour, and not the intensity.

•Gamma:The light output of a CRT is not linear with respect to the voltage input. The difference between what you should have and what is actually output is known as gamma.

•Frame: In interlaced video, a frame is one complete image. A video frame is made up of two fields, or two sets of interlaced lines. In a film, a frame is one still image of a series that makes up a motion image.

•Genlock: Allows synchronisation of otherwise video devices. A signal generator provides a signal pulses which connected devices can reference. Also see Black Burst and Color Burst.



[©] Xiamen RGBlink Science & Technology Co., Ltd. Ph: +86 0592 5771197 | support@rgblink.com | www.rgblink.com

•Blackburst: The video waveform without the video elements. It includes the vertical sync, horizontal sync, and the Chroma burst information. Blackburst is used to synchronize video equipment to align the video output.

•ColourBurst: In colour TV systems, a burst of subcarrier frequency located on the back part of the composite video signal. This serves as a colour synchronizing signal to establish a frequency and phase reference for the Chroma signal. Colour burst is 3.58 MHz for NTSC and 4.43 MHz for PAL.

•Colour Bars: A standard test pattern of several basic colours (white, yellow, cyan, green, magenta, red, blue, and black) as a reference for system alignment and testing. In NTSC video, the most commonly used colour bars are the SMPTE standard colour bars. In PAL video, the most commonly used colour bars are eight full field bars. On computer monitors the most commonly used colour bars are two rows of reversed colour bars

•Seamless Switching: A feature found on many video switchers. This feature causes the switcher to wait until the vertical interval to switch. This avoids a glitch (temporary scrambling) which often is seen when switching between sources.

•Scaling: A conversion of a video or computer graphic signal from a starting resolution to a new resolution. Scaling from one resolution to another is typically done to optimize the signal for input to an image processor, transmission path or to improve its quality when presented on a particular display.

•PIP: Picture-In-Picture. A small image within a larger image created by scaling down one of image to make it smaller. Other forms of PIP displays include Picture-By-Picture (PBP) and Picture- With-Picture (PWP), which are commonly used with 16:9 aspect display devices. PBP and PWP image formats require a separate scaler for each video window.

•HDR: is a high dynamic range (HDR) technique used in imaging and photography to reproduce a greater dynamic range of luminosity than what is possible with standard digital imaging or photographic techniques. The aim is to present a similar range of luminance to that experienced through the human visual system.

•UHD: Standing for Ultra High Definition and comprising 4K and 8K television standards with a 16:9 ratio, UHD follows the 2K HDTV standard. A UHD 4K display has a physical resolution of 3840x2160 which is four times the area and twice both the width and height of a HDTV/FullHD (1920x1080) video signal.

•EDID: Extended Display Identification Data. EDID is a data structure used to communicate video display information, including native resolution and vertical interval refresh rate requirements, to a source device. The source device will then output the provided EDID data, ensuring proper video image quality.



6.4 Revision History

The table below lists the changes to the Video Processor User Manual.

Version	Time	ECO#	Description	Editor
V1.0	2021-09-22	0000	Release	Sylvia
V1.1	2021-12-08	0001	Update product picture	Sylvia

All information herein is Xiamen RGBlink Science & Technology Co Ltd. excepting noted. RGBlink is a regis

tered trademark of Xiamen RGBlink Science & Technology Co Ltd.While all efforts are made for accuracy at time of printing, we reserve the right to alter otherwise make change without notice.