

Product and Technical News in March 2018

VENUS X2

Version: V2.46

- **Optimization**

1. The SDI output module supports the output format as the follows,

[1080p@60/59.94/50、1080p@30、1080i@50/59.94/60](#)

2. 4K@30 input module.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

VENUS X3

Version: V1.99

- **Problem Solved**

1. The TP color is incorrect from SDI output module.

2. The switching would get choppy within D-SDI inputs. (D-SDI MCU_V1.37)

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

VENUS X7

Version: V2.06

- **Update**

1. Black the screen via T1.

- **Problem Solved**

1. The layout of 4K signal would out of order.

2. The screen would show blurred after factory reset.

3. The switching would get choppy within D-SDI inputs. (D-SDI MCU_V1.37)

- **Download link for latest software**

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen, Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: support@rgblink.com <http://www.rgblink.com>

Contact sales or customer support personnel of RGBlink to get the latest software.

M1

Version: V1.40

- **Update**

- 1. Press signal buttons on PGM bar to switch the images on LED display directly.**
- 2. Adds the Duration Setting for TAKE.**
- 3. Adds the function of SAVE and LOAD.**
- 4. Adds the function of FREEZE for PST.**
- 5. Adds the function of BLENDING for layer B.**
- 6. Adds the function of DSK for layer B.**

- **Download link for latest software**

(EN) http://www.rgblink.com/en/products_detail.aspx?id=749

(CN) http://www.rgblink.com/products_detail.aspx?id=748

Contact sales or customer support personnel of RGBlink to get the latest software.

XONE

Version: V1.0.0.30

To control X7

- **Update**

- 1. Adds the function of Auto TAKE**
- 2. Adds the function of Zoom In/Out for Containers.**
- 3. Adds the function of TAKE for multi containers.**
- 4. Monitors would move via joystick.**

- **Optimization**

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen, Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: support@rgblink.com <http://www.rgblink.com>

- 1. The monitors can be dragged into the operation area directly. Do not need to build the container.**
- 2. The 13th-16th function buttons would light off.**
- 3. Signals show as a list in the left side.**
- 4. Pressing BLACK button, only PGM output would be black.**

To control X3

- **Update**

- 1. Adds the function of Auto TAKE.**
- 2. Adds the function of Hide/Show “PREVIEW”.**

- **Optimization**

- 1. The 13th-16th function buttons would light off.**
- 2. Signals show as a list in the left side.**

- **Problem Solved**

- 1. The crash would happen when the script is loaded.**

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.