

Product and Technical News in Dec. 2018

C1US

Version: V1.38

- **Optimization**

1. The boot LOGO would be shown when the device is power on.

- **Problem Solved**

1. The SCALE parameters would go wrong when output resolution is changed.

2. After reboot and set the CROP parameters, then the blurred screen would show.

- **Download link for latest software**

(EN) https://rgblink.com/en/products_detail.aspx?id=758

(CN) https://www.rgblink.cn/products_detail.aspx?id=762_

Contact sales or customer support personnel of RGBlink to get the latest software.

M1

Version: V2.07

- **Problem Solved**

1. Sometimes, the PST and PGM screens would flash to black and back to normal quickly.

2. When the signal connects to the first input module and display, some flash points would be shown.

3. The HDMI and SDI signal would be abnormal when M2 is rebooted.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen, Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: support@rgblink.com <http://www.rgblink.com>

X1pro e

Version: V1.27

- **Update**

1. The rotation function is added for Layer A.
2. DVI 2 and DP can input multiple signal with different resolution and the pixel-by-pixel splitting with multiple outputs can be achieved.

- **Problem Solved**

1. There would be a pixel missing at the top of screen.

Please pay attention to the follow:

When the software version of X1pro e is updated to V1.27 from V1.17(the last version), and rebooted. The problem of LOGO function doesn't work or the button lights flash abnormally would occur, then reset the device to factory default setting and reboot it please.

- **Download link for latest software**

(EN) https://rgblink.com/en/products_detail.aspx?id=754_

(CN) https://rgblink.cn/products_detail.aspx?id=753

Contact sales or customer support personnel of RGBlink to get the latest software.

M2

Version: V2.04

- **Optimization**

1. USB MANEGEMENT

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen,Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: support@rgblink.com <http://www.rgblink.com>



1) In default status, the USB signal would be still on PVW and PST monitor. And the USB play setting can be managed.

2) The USB signal would play when it's switched to PGM.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

VENUS X1

Version: V2.44

- **Optimization**

1. The Authorization Control function is optimized.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

C1

Version: V1.19

- **Problem Solved**

1. Pressing HDMI or CVBS buttons over and over again, and the buttons would get stuck.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

C1US

Version: V2.21

- **Problem Solved**

1. When the Crop Parameters is less than 320 pixels, and reboot the device, the blurred screen issue would occur.

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen, Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: support@rgblink.com <http://www.rgblink.com>



2. Connect to Nova MCTRL 660 Controller or YDEA LED Control System, the blurred screen issue would occur.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

RS1

Version: V2.22

- **Update**

1. The USB interface on front panel is used for Connection instead of Update.

- **Problem Solved**

1. Under Rotation Mode, the blurred screen issue would occur when the device is rebooted.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

D6

Version: V2.12

- **Update**

1. The output resolution of HDMI 2.0 output modules can be set independently.

- **Problem Solved**

1. Under Presentation or Preview Mode, the layer would miss when the position is changed.

2. The display would be incomplete when the output resolution of HDMI 2.0 output module is changed.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen, Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: support@rgblink.com <http://www.rgblink.com>

VENUS X3

Version: V2.50

- **Update**

1. The X3p logo would show on the LCD panel when the device is power on.

- **Problem Solved**

1. The OSD text that show on PVW output would be fuzzy. The problem is solved as the MCU version of PVW module is V2.05.
2. It would be failure to do the factory reset for X3(with PVW modules) via T1.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

FLEX 16

Version: V1.24

- **Update**

1. The EDID Management Setting can be set via front panel. It works to manage the frequency to 50Hz or 60Hz for inputs.

- **Optimization**

1. Under Splitting Mode, the switching effect would not be well.

- **Problem Solved**

1. The HDMI signal would show abnormally when the device is rebooted.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.