



## Product and Technical News in Apr. 2019

### D4

#### Version: V2.08

##### ● Update

1. Adds DP output.
2. Adds the function of CROP, MASK and scale reset.
3. Adds the setting of customized resolution.
4. It's available for TP, FREEZE and DIMMER buttons.
5. The transition function is available for Cut,Fade and Duration setting.
6. Adds output adjustment function.
7. Adds language menu for Chinese/English switching.
8. Adds the HDR function for DP input, and the DP input module should be plugged into the 2<sup>nd</sup> slot.
9. The function of color space identification is added for Input menu, and the function of module identification and details is added for DP output module.
10. Adds the audio select and switch.
11. Adds HDR button on front panel.

##### ● Problem Solved

1. Three pixels would be lost on the top when the 4K signal is selected.
2. When it's full loaded with 4K2K@60 input and 4K2K@60 output, the display would be flutter when it's switched.

##### ● Download link for latest software

Contact sales or customer support personnel of RGBlink to get the latest software.

### X3

#### Version: V2.62

##### ● Update

1. The version number of PVW module is shown on front panel.

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen,Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: [support@rgblink.com](mailto:support@rgblink.com) <http://www.rgblink.com>

1 / 4



- **Optimization**

1. The problem of dark and bright line of 4K input module.
2. With DVI output module, the image would be abnormal when the device is rebooted.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

## **T1**

**Version: V1.0.1.12**

**(Software version of X3: V2.62)**

- **Update**

1. The Device Type and Serial Number of D4 can be detected.
2. The H.264 setting menu is added.
3. Adds a H.264 switch in Bank preset menu. When the PVW output is extended to the monitor via HDMI/DP, and it would force the Bank preset menu shutdown and show the IP streaming preview.

- **Problem Solved**

1. The frame rate can only be 18Hz.

- **Optimization**

1. The default aspect ratio is changed to 1:4.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

## **FLEX 8**

**Version: V1.32**

- **Optimization**

1. Matrix Mode: The distribution for 8 signals is available.
2. Split Mode: The EXT4F-OS output module is available for splitting.

**Controlled via XPOSE v1.2.7.0**

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen, Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: [support@rgblink.com](mailto:support@rgblink.com) <http://www.rgblink.com>

2 / 4



- **Download link for latest software**

(EN) [https://rgblink.com/product-detail?id=822\\_\\_](https://rgblink.com/product-detail?id=822__)

(CN) [https://www.rgblink.cn/product-detail-cn?id=823\\_\\_](https://www.rgblink.cn/product-detail-cn?id=823__)

Contact sales or customer support personnel of RGBlink to get the latest software.

## **X1pro/X1pro e**

- **Update**

1. The program version is downgraded to V2.14 from V2.16 for the VGA, SDI, CVBS, USB and input modules.

From April 30<sup>th</sup> 2019, the optional input modules are in common use for X1, X1pro and X1pro e.

## **GX4/C1US**

**Version: V1.53**

- **Problem Solved**

1. The display would flutter when the output connect to Nova sender with customized resolution.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.

## **XPOSE 2.0**

**Version: V2.0.0.11**

- **Update**

1. Adds Register and Activation function(networking is required)

2.Adds LOGO setting.

3.Adds EDID setting.

4.Press shortcut key Ctrl+left mouse button for layer copy function.

5.Press shortcut key Ctrl+A to select all of the layers, Ctrl+D to cancel the selection, and press Delete button to delete the layer.

6.Adds the function of Bank Copy and Paste: Ctrl+A for select all, Ctrl+C for Bank copy, Ctrl+V for Bank paste.

Address: S601 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen,Fujian P.R.C

Tel: 4008 592 315

Fax: +86 592 5788216

Email: [support@rgblink.com](mailto:support@rgblink.com) <http://www.rgblink.com>



7.It's available to change the names and color of the Banks.

8.Adds the file path for the saved script.

9.The Russian menu is available.

10.It's available to control multiple devices via network.

- **Optimization**

1. The interface of 4K60 input setting menu.

2.The settings of output resolution. It's available to set a output resolution for all of the output modules or set the different resolution for each output module separately.

3.When the output resolution is set, the display area and the size of monitor would not be changed.

4.The settings of CROP in layer management menu.

- **Download link for latest software**

Contact sales or customer support personnel of RGBlink to get the latest software.