

# M2 Quick Start



- Integrated Vision Mixer & Scaler
- 5 mega pixel capacity
- Three output option modes Dual 2K, 4Kx1K & 4K
- Select or set output resolutions to any requirement
- Dedicated source Preview output with Multiview
- Wide range of transition effects built in
- Up to 3 video layers including background for presentation Program to Preview applications
- Position, Scale, Crop video layers freely
- DSK/Key on foreground video layers
- Wide range of Masks can be applied to any foreground video layer
- Variable edge blending on foreground layers
- Additional 3 independent layers for OSD, LOGO and STILL
- Tally support built-in
- Genlock support built-in
- Modular construction

# CONTENT

Product Introduction	2
Packing Configuration	
Hardware Orientation	4
Front Panel	
Back Panel	
Using Your Product	12
Menu Structure	
PST Mode	
PGM Mode	
4K1K Mode	20
Presentation Mode	21
Switching Mode	23
Set the Output Resolution	
Adjust R,G,B of SDI,VGA,CVBS,USB input	26
Using Black Out	
Saving Views	29
Recall Saved Settings	
Contact Information	


## Product Introduction

All-in-one scaling and mixing just got even better.

Now you choose input options, now you configure output operations, now control transitions from the t-bar, now apply layer masks, now do more.

M2 redefines modern hands on scaling and mixing for any environment.


Totally modular and flexible in configuration, M2 is packed with standard features to impress and present with ease.



2

#### M2 System Connection Diagram

## Packing Configuration






#### Note:

AC Power Cable supplied as standard according to destination market.

## Hardware Orientation

### **Front Panel**



Panel Ins	Panel Instruction		
1	Layer adjustment area	8	Layer mask area
2	Layer selection area	9	Transition area
3	Layer effect area	10	Functions area
4	Multiview presets area	11	Independent effects switching area
5	Stored presets area	12	OSD edit area
6	Input sources area	13	Switch modes area
7	Menu and OLED display area		

#### Layer Adjustment Area

	SCALE
	This button used for size and crop adjusting. If image quality distorts by improper
	operation, it can be recover by reset.
	POS
	This button used for position adjusting. If image quality distorts by improper operation,
	it can be recover by reset.
	<u>FS</u>
	Screen parameters setting button. Push the button, its LED light turns on, user can
	choose full size or screen size.
	FREEZE
	Freeze the image or video.
1	Rotary Knob
	For size and position adjustment and confirmation.
	Push SCALE and control the rotary knob will active the display window to be ready for
	size down.
	Push POS and control the rotary knob will active the display window to be ready for
	change position.
	Joystick
	For size and position adjustment.
	Push SCALE and control the joystick will activate the display window to be ready for size
	down.
	Push POS and control the joystick will activate the display window to be ready for
	change position.

#### Layer Selection Area

	A/B/C/D
2	For adding or deleting the layer, the button light is lit when add the layer, off when
	delete the layer, and flash when select the layer.

#### Layer Effect Area

	DSK
	DSK effect editing button. User can select the layer and set the position in DSK menus.
	BLEND
3	BLEND effect editing button. User can select the layer and set the blending width in
5	BLEND menus.
	Rotary Knob
	Adjust the alpha of DSK layer.
	For DSK and BLEND adjustment and confirmation.
	5 RGB

© Xiamen RGBlink Science & Technology Co., Ltd.

#### **Multiview Presets Area**

	Multiview Presets
	Multiview mode selection, the button light is lit when selected, mainly for layout
	setting quickly in multiview.
	IIP
4	PIP CENT
	E 3P.
	:4p,under Presentation 2K1K mode

#### **Stored Presets Area**

	SAVE
	Support 36 saving modes.
	LOAD
	Load saving views 1 to 36.
5	PAGE
	For save or load, total 6 pages, and 6 banks for each page.
	<u>1/2/3/4/5/6</u>
	The button is lit when select PAGE or BANK.

#### **Input Sources Area**

	LED Indicator
	The button 1/2/3/4/5/6/7/8 is lit when the signal or background input is selected for
	use.
	PGM Area
	For indicating, user can not change the channel or set the size or position in PGM area.
	<u>BK1/2</u>
6	For indicating, the button is lit when enable background function.
	<u>1/2/3/4/5/6/7/8</u>
	Each button is numbered and can be used as direct number entry when values such as
	resolution and size.
	PST Area
	For indicating, the button is lit when output the signal in PST channel.
	For selecting, push any button to switch the PST signal.
	6 <b>RGBlink</b> <sup>®</sup>


© Xiamen RGBlink Science & Technology Co., Ltd.

	For editing, (button light is lit the channel is used but can not be edited, button light
	is flashing the channel can be edited, button light is off the channel is not selected.

#### Menu and OLED Display Area

	MENU
	Menu and exit reuse button.
	SELECT/ENTER
7	Confirmation button.
	OLED Display
	Displays current status of the product, and for feature selections provides interactive
	choices in conjunction with buttons on the front panel.

#### Layer Mask Area




#### **Transition Area**

	$\boxed{\textcircled{H}}_{: \leftarrow + \rightarrow}$	
9	$\boxed{\vdots} \div \Box \rightarrow$	

© Xiamen RGBlink Science & Technology Co., Ltd.

Ph: +86 592 5771197 | support@rgblink.com | www.rgblink.com

**RGBlink**<sup>®</sup>



#### **Functions Area**

	LOGO
	Enable or disable the LOGO function. If select "ON", user can set the X and Y, or load file
	from UDisk.
	<u>STILL</u>
	Enable or disable the STILL function. If select "ON", user can set the X and Y, or load file
	from UDisk.
	<u>OSD</u>
10	Enable or disable the OSD function. If select "ON", user can delete the OSD, or load file
10	from UDisk.
	<u>BK</u>
	The button is lit when enable black function. Black is available for PGM channel.
	LOCK
	Lock top panel button. The button is lit when the buttons in top panel are locked. Push
	the button again, the button light is off, and unlock the top panel.
	Indicator
	The indicator is on when the output format is SD, HD, RGB, 4K1K, 4K2K or CUST.

#### **Independent Effects Switching Area**

	PGM OUT			
11	1/2 button: Independent effects switching for PGM1 or PGM2.			
11	GROUP: Effects switching for PGM1 or PGM2 at the same time under the			
	Presentation Group mode.			

8

© Xiamen RGBlink Science & Technology Co., Ltd.

Ph: +86 592 5771197 | support@rgblink.com | www.rgblink.com

**RGBlink**<sup>®</sup>


#### **OSD Edit Area**

	OSD
	: Subtitle rows back button.
12	: Subtitle rows forward button.
	OSD TAKE
	Subtitles switch button.

#### Switch Mode Area

	<u>CUT</u>				
	Seamless switching.				
12	TAKE				
13	Seamless switching with effect.				
	<u>T-BAR</u>				
	WIPE and mix switching.				

9 © Xiamen RGBlink Science & Technology Co., Ltd.



#### **Input Slots**

		3 input card slots support for 9 single modules, including DVI, VGA, HDMI, USB, CVBS, DP and SDI.
Ontional		Each DVI module supports 1 DVI-I input.
Optional		Each VGA module supports 1 DB15 input.
Input	1	Each HDMI module supports 1 HDMI-A input and 1 HDMI loop out.
Module		Each USB module supports 1 USB-A input and 1 USB backup.
		Each CVBS module supports 1 BNC input and 1 BNC backup.
		Each DP module supports 1 DP input.
		Each SDI module supports 1 SDI input and 1 SDI loop out.

#### Output

PGM Output	2.3	HDMIx2
PST Output	4.5	HDMIx2
PVW	8	HDMIx1
Output	9	VGAx1

#### Communication

6. 7	TALLY light DB15x2
12	Genlock - BNC x1
13	USB x1
14	Serial port RS-232x1
15	LAN port RJ-45x1

10

RGBlink

© Xiamen RGBlink Science & Technology Co., Ltd.

#### Power


10	Power Switch	
11	AC 85-264V Max 65W, IEC-3	



# Using Your Product

### Menu Structure

The menu structure is shown in the figure below:



**RGBlink**<sup>®</sup>

© Xiamen RGBlink Science & Technology Co., Ltd.

Ph: +86 592 5771197 | support@rgblink.com | www.rgblink.com

### PST Mode

M2 supports 2 HDMI preview output, and it supports the functions as below:

#### **Signal Selection**

Push any button in Input Sources Area, for example, push the button [5], the border of signal 5 will change to yellow, and the signal in PGM monitor will be changed to signal 5.

#### Add or Delete Layer

Push any button of [A] to [D] in Layer Selection Area to add or delete the layer. Add layer: The light is lit. Select layer: The light is flashing. Delete layer: The light is off.

#### **Freeze the Layer**

Push the [FREEZE] button in Layer Adjustment Area, the layer will be freeze, push the button again, the layer is live.

#### **Multiview Presets**

- 1. Push any button in Multiview Presets Area to select multiview layouts, including 1P, PIP CENT and 3P.
- 2. User can adjust the position, size for the selected layer, and set DSK, BLEND and MASK.

#### **Set the Position**

- 1. Push any button of [A] to [D] in Layer Selection Area, the light is flashing when the layer is selected.
- 2. Push the [POS] button in Layer Adjustment Area, and enter to the menus as follows:

->H Pos	120
V Pos	329
Reset	>>

Use the rotary knob or joystick to adjust the position of the layer. When swing the joystick to the left or right, the horizontal position will be changed. When swing the joystick up or down, the vertical position will be changed.

#### Scale and Crop the Layer

1. Push any button of [A] to [D] in Layer Selection Area, the light is flashing when the layer is selected.

13

2. Push the [SCALE] button in Layer Adjustment Area, and enter to the menus as follows:



->H Size	1920
V Size	1080
Reset	>>
Crop	>>

Use the rotary knob or joystick to adjust the size of the layer.

When swing the joystick to the left or right, the horizontal size will be changed.

When swing the joystick up or down, the vertical size will be changed.

If select <Crop>, it will enter to the menus as follows:

Crop H Pos: Crop the horizontal position.

**Crop V Pos:** Crop the vertical position.

Crop H Size: Crop the horizontal size.

Crop V Size: Crop the vertical size.

**Crop Reset:** Reset crop if image quality distorts by improper operation.

#### **DSK Setting**

- 1. Firstly, enable the multiview function.
- 2. Push [MENU] button, and enter to the menu items. Turn the rotary knob, and select <DSK> option in <Advance>, push the knob to confirm. (Or push the [DSK] button to enter to the DSK menu items)

->Layer	Layer 1
Preset	Black BackGround
Mode	Key In
Alpha	128
->Red Min	0
Red Max	208
Green Min	0
Green Max	208
->Blue Min	0
Blue Max	208
DSK	ON

Layer: Select the layer that will DSK.

**Preset:** Can select user, black background, green background, blue background, red background and white background.

Mode: Select Key In or Key Out.

Alpha: The adjustment range is between 0~128.

Red Min: The adjustment range is between 0~255.

14



© Xiamen RGBlink Science & Technology Co., Ltd.

Red max: The adjustment range is between 0~255. Green Min: The adjustment range is between 0~255. Green Max: The adjustment range is between 0~255. Blue Min: The adjustment range is between 0~255. Blue Max: The adjustment range is between 0~255. DSK: Can select enable or disable the DSK function.

#### **BLEND Setting**

- 1. Firstly, enable the multiview function.
- 2. Push [MENU] button, and enter to the menu items. Turn the rotary knob, and select <Blending> option in <Advance>, push the knob to confirm. (Or push the [BLEND] button to enter to the BLEND menu items)

->Layer	Layer 1
Blending Width	50
ON/OFF	ON

Layer: Select the layer that will blending.

**Blending Width:** Blending width setting, the adjustment range is between 1~90. **ON/OFF:** Enable or disable the blending function.

#### **Mask Setting**

- 1. Push the [MENU] button, and enter to the menu items.
- 2. Turn the rotary knob, and select <Mask> option in <Advance>, push the knob to confirm:

->Mask	Heart
Layer	Layer 1
ON/OFF	ON
Mask&PIC Pox X	50
->Mask&PIC Pox Y	50
Mask Pox X	50
Mask Pox Y	50
PIC Pox X	50
->PIC Pox Y	50
Load File From UDisk	No

#### Enable the mask function:

Turn the rotary knob, select <ON/OFF>, and set "ON" to enable the mask function.

15



© Xiamen RGBlink Science & Technology Co., Ltd.

#### Select mask:

Turn the rotary knob, and select <Mask>, push the knob to confirm. Turn the rotary knob, and select the effects, diamond, round, heart, star, triangle, oval, hexagons, pentagon, 4 point star, 6 point star, lighting, crescent left and crescent right.

User can also push the layer mask selection button in Layer Mask Area to select the mask.

#### Mask setting:

M2 supports load file from UDisk, and set the selected layer, including effect & PIC Pos X, Y, effect X, Y and PIC Pos X, Y.

#### Custom the mask:

There are 2 custom buttons in Layer Mask Area, push [CUST1] or [CUST2], for example, push [CUST1], it will enter to the menus as follows:

->Custom 1	Heart
Layer	Layer 1
ON/OFF	ON
Mask&PIC Pox X	50

Turn the rotary knob, and select <Custom 1>, push the knob to confirm. Turn the rotary knob again, and select the mask, for example, select <Star>, push the knob to confirm.


Then push the [CUST1] button, the custom will change to the mask that set, as shown below:

->Custom 1	Star
Layer	Layer 1
ON/OFF	ON
Mask&PIC Pox X	50

16

#### **Transitions Setting**

1. Push the transition buttons in Transition Area, M2 supports 8 kinds of wipe modes:



**RGBlink**<sup>®</sup>

© Xiamen RGBlink Science & Technology Co., Ltd.

Push the transition button  $\downarrow$ , user can select III $\rightarrow$ .

Push the transition button  $\square$ , user can select  $LT \rightarrow RB$ .

2. Push the [TAKE] button, or use T-bar switcher to switch the image to program with selected wipe.

#### **Custom LOGO**

Push [MENU] button, and enter to the menu items. Turn the rotary knob, and select <LOGO> option in <Advance>, push the knob to confirm, (Or push the [LOGO] button in Functions Area) it will enter to the LOGO menus as below:

->LOGO	1
ON/OFF	OFF
X	1600
Y	952
->Delete	1
Load File From UDisk	No UDisk

#### Enable the LOGO function:

Turn the rotary knob, select <ON/OFF>, and set "ON" to enable the logo function.

#### LOGO Setting:

1. Turn the rotary knob, and select <LOGO>, push the knob to confirm.

- 2. Turn the rotary knob, and select the LOGO that to custom, push the knob to confirm.
- 3. Turn the rotary knob, select <X> or <Y>, and set the position of LOGO.

Additionally, M2 supports load file from UDisk.

#### **Custom OSD**

Push [MENU] button, and enter to the menu items. Turn the rotary knob, and select <OSD> option in <Advance>, push the knob to confirm, it will enter to the OSD menus as below:


->ON/OFF	OFF
Delete	No
Load File From UDisk	No

- 1. Turn the rotary knob, select <ON/OFF>, and select "ON" to enable the OSD function.
- 2. Turn the rotary knob, select <Delete>, and select "Yes" to delete the OSD.
- 3. Turn the rotary knob, select <Load File From UDisk>, and select "Yes" to load the OSD file from UDisk.



#### **Custom STILL**

Push [MENU] button, and enter to the menu items. Turn the rotary knob, and select <Still> option in <Advance>, push the knob to confirm, (Or push the [STILL] button in Functions Area) it will enter to the STILL menus as below:



#### Enable the STILL function:

Turn the rotary knob, select <ON/OFF>, and set "ON" to enable the logo function. **STILL Setting:** 

1. Turn the rotary knob, and select <Still>, push the knob to confirm.

2. Turn the rotary knob, and select the Still that to custom, push the knob to confirm.

3. Turn the rotary knob, select <X> or <Y>, and set the position of Still.

Additionally, M2 supports load file from UDisk.

### PGM Mode

- 1. Switch the edited PST image to program by pushing the [CUT], [TAKE] button or T-bar, and then the PGM image will return to PST state, which can be edited.
- 2. There are 2 HDMI outputs for program, and realize 4Kx1K output.

**RGBlink**<sup>®</sup>

1. Push the [MENU] button, and enter to the menu items, turn the rotary knob, and select <Output>.

Input	>>
->Output	>>
Background	>>
Advance	>>

2. Push the knob to confirm. Turn the rotary knob, and select <4K1K>, push the knob to confirm:

Format	1920×1080×60
Custom Format	>>
->4K1K	>>
Color Space/Sample/Bit	>>

3. Turn the rotary knob, select <4K1K>, and set "ON":

->4K1K	ON
H Total	3600
V Total	1080
PGM1 H Size	1920
->Set	No

4. Turn the rotary knob, and set H Total as 3840, then it realizes the 4K1K mode.

4K1K	ON
->H Total	3840
V Total	1080
PGM1 H Size	1920

### Presentation Mode

(1) Press the MENU button, enter to the main menu. Turn the knob and select <Output>:


(2) Press the knob to confirm. Turn the knob, select <Presentation> under <System Mode>, press the knob to confirm:



(3)Under Presentation, users can choose Presentation 2K1K and Presentation Group. OLED will show as follow:

Presentation 2K1K	>>
Presentation Group	>>


(3) Presentation 2K1K mode allows 1 output displays 4 layers as the following example.



21

(5)Presentation Group mode allows PGM1 and PGM2 to be switched at the same time.

Layers A,B,C are on PST1 and Layer D on PST2. When PST1 is selected, users can change the input source and layout of Layer A,B,C and switch to PGM1 by **TAKE** button or **T-Bar**. When PST2 is selected, users can change input source and layout of Layer D and switch to PGM2 by **TAKE** or **T-Bar**. Under the Presentation Group mode, PST1 and PST2 are switched to PGM1 and PGM2 by **TAKE** button at the same time. Please note that T-Bar doesn't work under Presentation Group mode.





### Switching Mode

- 1. T-BAR switch: Switch the PST image to program with wipe and fade by T-bar.
- 2. CUT switch: Seamless switch the PST image to program by pushing [CUT] button.
- 3. TAKE switch: Switch the PST image to program with wipe and fade by pushing [TAKE] button.
- 4. TRANSITION DURATION: Transition duration setting, the adjustment range is between 0~9.9S.

#### **Select the Output Resolution**

1. Push the [MENU] button, and enter to the menu items, turn the rotary knob and select <Output>:

Input	>>
->Output	>>
Background	>>
Advance	>>

2. Push the rotary knob to confirm, and enter to the menus as below:

->Format	1920×1080×60	
Custom Format	>>	
4K1K	>>	
Color Space/Sample/Bit	>>	

3. <Format> is the default option, push the rotary to confirm. Turn the rotary knob, select the output resolution according to actual need.

#### **Custom the Output Resolution**

1. Push the [MENU] button, and enter to the menu items, turn the rotary knob and select <Output>:

Input	>>
->Output	>>
Background	>>
Advance	>>


2. Push the rotary knob to confirm, and enter to the menus as below:

->Format	1920×1080×60	
Custom Format	>>	
4K1K	>>	
Color Space/Sample/Bit	>>	

24

3. Turn the rotary knob, and select <Custom Format>, push the rotary knob to confirm.

© Xiamen RGBlink Science & Technology Co., Ltd.



4. Set H Active, V Active and Fred according to actual need, then select <Set> and set "Yes", push the rotary knob to confirm.



### Adjust R,G,B of SDI,VGA,CVBS,USB input

M2 of Version 2.13 allows users to adjust the value of RGB of SDI,VGA,CVBS,USB input.

PST Input	:VGA
Output Forma	at:1920x1080@60
System Mode	e : Normal
SN:0229	Version:2.13

Here are the operation.

Enter Menu of Input

>>
>>
>>
>>

Find the Chanel of SDI,VGA,CVBS or USB. Users can preview the input from the output display. For example, SDI input in Chanel 8.

Ch.5	IN5_DVI
Ch.6	IN6_HDMI
Ch.7	IN7_HDMI
->Ch.8	IN8_SDI

Enter Chanel 8 and find Ch.8 Control

Ch.8	IN8_SDI
Input Format	1280x720@60
->Ch.8 Control	>>

Enter Ch.8 Control menu, there are items to adjust R,G,B

BRIGHTNESS RED	50
BRIGHTNESS GREEN	50
BRIGHTNESS BLUE	50
CONTRAST	50
SATURATION	50
SHARPNESS	50
COLOR TEMP RED	50
COLOR TEMP GRN	50

26



© Xiamen RGBlink Science & Technology Co., Ltd.

COLOR TEMP BLUE 50 Reset

Brightness R,G,B value range from 0 to 100

**Contrast** range from 0 to 100

Saturation rang from 0 to 100

Sharpness range from 0 to 100

Color Temp R,G,B value range from 0 to 255





### Using Black Out

Black out description:

Black signal realizes one-key-touch to a black screen.

M2 provides black effect processing for program output and preview output, with cut black effect. Operation is as below:

Push the [BLACK] button, the button light is lit, then the program output is cut to black.

The effect is shown as below:







28



© Xiamen RGBlink Science & Technology Co., Ltd.

### Saving Views

M2 provides 36 positions for saving or recording parameters. To save current parameters and settings:

1. Push the [SAVE] button in Stored Presets Area, the button [SAVE] and [PAGE] lights are lit, and some of buttons 1~6 are lit and some are flashing. The button lit can be saved and flash will be overwrite, push the button lit to save.



2. Select PAGE, for example, the button [2] is lit, push the button [2].

SAVE TO	
->PAGE: 2	
BANK: 1	
Backup To UDisk	No UDisk

3. After set the PAGE, it will jump to BANK option, or example, the button [2] is lit, push the button [2]:

SAVE TO	
PAGE: 2	
->BANK: 2	
Backup To UDisk	No UDisk

- 4. Push the [SAVE] button again, the button light is off, and exit the save function.
- 5. Select <Backup To UDisk>, user can save the parameters to the UDisk.



### **Recall Saved Settings**

M2 provides 36 positions for saving or recording parameters. To recall saved settings:

 Push the [LOAD] button in Stored Presets Area, the button [LOAD] and [PAGE] lights are lit, and some of buttons 1~6 are lit and some are flashing. The button lit is ready for recall and flash means just recall, push the button lit to recall.



2. Select PAGE, for example, the button [2] is lit, push the button [2].

LOAD FROM	
->PAGE: 2	
BANK: 1	
Load From UDisk	No UDisk

3. After set the PAGE, it will jump to BANK option, or example, the button [2] is lit, push the button [2]:

LOAD FROM	
PAGE: 2	
->BANK: 2	
Load From UDisk	No UDisk

- 4. Push the [LOAD] button again, the button light is off, and exit the load function.
- 5. Select <Load From UDisk>, user can load the saved parameters from the UDisk.



## **Contact Information**

### Warranty:

All video products are designed and tested to the highest quality standard and backed by full 3 years parts and labor warranty. Warranties are effective upon delivery date to customer and are non-transferable. RGBlink warranties are only valid to the original purchase/owner. Warranty related repairs include parts and labor, but do not include faults resulting from user negligence, special modification, lighting strikes, abuse(drop/crush), and/or other unusual damages.

The customer shall pay shipping charges when unit is returned for repair.

Headquarter: S603~604 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen, Fujian Province, P.R.C

- Tel: +86-592-5771197
- **Fax:** +86-592-5788216
- Customer Hotline: 4008-592-315
- Web:
  - ~ http://www.rgblink.com
  - ~ http://www.rgblink.cn
  - E-mail: support@rgblink.com